



Installation guide
Solenoid valve
Type EV227B

032R9277


032R9277




1




2




3



4



5



6

